

Baofeng UV-B5 / B6

Manual Programming

Enter the VFO Mode

- Press [VM/SCAN] to enter VFO (frequency mode)

Enter 'SHIFT'

- Press [MENU] , then (channel knob) to Menu 21 (SHIFT)
- Press then (channel knob) to select + - 0
- Press to save.
- Press [MENU] or any key to exit.

Enter 'OFFSET'

- Press [MENU] , then (channel knob) to Menu 22 (OFFSET)
- Press then enter the offset
- Press to save.
- Press [MENU] or any key to exit.

Enter 'TCODE' (CTCSS / DCS)

- Press [MENU] , then (channel knob) to Menu 12 (TCODE)
- Press then [MENU] to select CTCSS / DCS / OFF
- Press (channel knob) to select desired code.
- Press to save.
- Press [MENU] or any key to exit.

Enter Frequency

- Using the keypad, enter the desired frequency.
- Press & Hold the [VM/SCAN] button to display channels 01-99
- Press (channel knob) to select the desired channel.

NOTE: If channel number is blinking, that channel has been previously programmed and will be overridden.

- Press to save.

Enter the MR Mode

- Press [VM/SCAN] to enter MR (channel mode).